32 address

FACILITY: Looney Tunes Theater

CABLE #: 1 ORIGINATOR: Scott B DATE: 4/3/

SOURCE: TSC DESTINATION: TS-1 Flat cable

1st address card →

Card 1 (card not 0)

ADDRESS-BIT			SIGNAL NAME	WIRE #		SIGNAL NAME
0	0	0	Bugs Bunny mouth	1	2	Actuator Power
0	0	1	Eyes & Head Left	3	4	Actuator Power
0	0	2	" " " Right	5	6	Actuator Power
0	0	3	Eyes up	7	8	Actuator Power
ERROR REPORT BUSS				9	10	Common
0	0	4	Eyes down	11	12	Actuator Power
0	0	5	Ear	13	14	Actuator Power
0	0	6	Head Rock	15	16	Actuator Power
0	0	7	Head Bob	17	18	Actuator Power
ERROR REPORT BUSS				19	20	Common
0	1	0	Body turn	21	22	Actuator Power
0	1	1	Body Bob	23	24	Actuator Power
0	1	2	L. Arm Lift	25	26	Actuator Power
0	1	3	L. elbow	27	28	Actuator Power
ERROR REPORT BUSS				29	30	Common
0	1	4	L. wrist	31	32	Actuator Power
0	1	5	R. Arm Lift	33	34	Actuator Power
0	1	6	R. elbow	35	36	Actuator Power
0	1	7	R. wrist (4- pos. manifold)	37	38	Actuator Power
ERROR REPORT BUSS				39	40	Common

Pay no attention

NOTES:

1 of 10

CABLE #: 2 ORIGINATOR: [illegible] DATE: 4/12/88

SOURCE: TSC DESTINATION: TS-2

ADDRESS-BIT	SIGNAL NAME	WIRE #		SIGNAL NAME
Ø 2 0	Bugs Bunny (cont.) 4-Pos. manifold Tail	1	2	Actuator Power
Ø 2 1	foot	3	4	Actuator Power
Ø 2 2	turntable Proportional Control	5	6	Actuator Power
Ø 2 3	" " "	7	8	Actuator Power
ERROR REPORT BUSS		9	10	Common
Ø 2 4	" " "	11	12	Actuator Power
Ø 2 5	" " "	13	14	Actuator Power
Ø 2 6	Daffy Mouth	15	16	Actuator Power
Ø 2 7	Eyes ~~Up~~ Eyes + Head Left	17	18	Actuator Power
ERROR REPORT BUSS		19	20	Common
Ø 3 0	~~Eyes Down~~ Eyes + Head Right	21	22	Actuator Power
Ø 3 1	Eyes ~~& Head L~~ Up	23	24	Actuator Power
Ø 3 2	Eyes ~~& Head R~~ Down	25	26	Actuator Power
Ø 3 3	Head Rock	27	28	Actuator Power
ERROR REPORT BUSS		29	30	Common
Ø 3 4	Head Bob	31	32	Actuator Power
Ø 3 5	Body turn	33	34	Actuator Power
Ø 3 6	Body Rock	35	36	Actuator Power
Ø 3 7	L. Arm	37	38	Actuator Power
ERROR REPORT BUSS		39	40	Common

last address card

NOTES:

CABLE #: 3 ORIGINATOR: Scott B. DATE: 9/2/86

SOURCE: TSC DESTINATION: TS-3

Card 2 (card slot 1)

ADDRESS-BIT	SIGNAL NAME	WIRE #		SIGNAL NAME
Ø 4 0	R. Wrist	1	2	Actuator Power
Ø 4 1	Blow-up mouth	3	4	Actuator Power
Ø 4 2	special effects manifold turntable	5	6	Actuator Power
Ø 4 3	Bomb doors	7	8	Actuator Power
ERROR REPORT BUSS		9	10	Common
Ø 4 4	firecracker	11	12	Actuator Power
Ø 4 5	Bomb	13	14	Actuator Power
Ø 4 6	Yosemite Sam mouth	15	16	Actuator Power
Ø 4 7	Eyes & Head L	17	18	Actuator Power
ERROR REPORT BUSS	[redacted]	19	20	Common
Ø 5 0	Eyes & Head R.	21	22	Actuator Power
Ø 5 1	Eyes Up	23	24	Actuator Power
Ø 5 2	Eyes down	25	26	Actuator Power
Ø 5 3	Eye Brows	27	28	Actuator Power
ERROR REPORT BUSS		29	30	Common
Ø 5 4	Head rock	31	32	Actuator Power
Ø 5 5	Head Bob	33	34	Actuator Power
Ø 5 6	Body turn	35	36	Actuator Power
Ø 5 7	Body Rock	37	38	Actuator Power
ERROR REPORT BUSS		39	40	Common

NOTES:

FACILITY: Looney Tunes Trailer

CABLE #: 4 ORIGINATOR: Scott B. DATE: 9/2/96

SOURCE: TSC DESTINATION: TS-4

ADDRESS-BIT	SIGNAL NAME	WIRE #		SIGNAL NAME
Ø 6 0	Yosemite Sam (cont.) L. Arm turn	1	2	Actuator Power
Ø 6 1	L. elbow	3	4	Actuator Power
Ø 6 2	L. Wrist	5	6	Actuator Power
Ø 6 3	R. Arm turn	7	8	Actuator Power
ERROR REPORT BUSS		9	10	Common
Ø 6 4	R. elbow	11	12	Actuator Power
Ø 6 5	R. Wrist	13	14	Actuator Power
Ø 6 6	Speedy Gonzales mouth	15	16	Actuator Power
Ø 6 7	Head turn	17	18	Actuator Power
ERROR REPORT BUSS		19	20	Common
Ø 7 0	Body Rock L.	21	22	Actuator Power
Ø 7 1	Body Rock R.	23	24	Actuator Power
Ø 7 2	Arms	25	26	Actuator Power
Ø 7 3	Lift	27	28	Actuator Power
ERROR REPORT BUSS		29	30	Common
Ø 7 4	Sylvester Sr. mouth	31	32	Actuator Power
Ø 7 5	Eyes & Head L.	33	34	Actuator Power
Ø 7 6	Eyes & Head R.	35	36	Actuator Power
Ø 7 7	Eyes Up, tail	37	38	Actuator Power
ERROR REPORT BUSS		39	40	Common

NOTES:

CABLE #: 5 ORIGINATOR: Scott B DATE: 9/2/86

SOURCE: TSC DESTINATION: TS-5

Card 3 (card slot 2)

ADDRESS-BIT			SIGNAL NAME	WIRE #		SIGNAL NAME
Φ	8	0	Sylvester Sr. (Cont.) Eyes down	1	2	Actuator Power
Φ	8	1	Head BOB	3	4	Actuator Power
Φ	8	2	Body Rock	5	6	Actuator Power
Φ	8	3	Body turn L.	7	8	Actuator Power
ERROR REPORT BUSS				9	10	Common
Φ	8	4	Body turn R.	11	12	Actuator Power
Φ	8	5	L. Arm up	13	14	Actuator Power
Φ	8	6	L. wrist	15	16	Actuator Power
Φ	8	7	R. Arm up	17	18	Actuator Power
ERROR REPORT BUSS				19	20	Common
Φ	9	0	R ~~wrist~~ elbow	21	22	Actuator Power
Φ	9	1	R. wrist	23	24	Actuator Power
Φ	9	2	Sylvester Jr. mouth	25	26	Actuator Power
Φ	9	3	Eyes up	27	28	Actuator Power
ERROR REPORT BUSS				29	30	Common
Φ	9	4	Eyes down	31	32	Actuator Power
Φ	9	5	Head L.	33	34	Actuator Power
Φ	9	6	Head BOB	35	36	Actuator Power
Φ	9	7	L. Arm up	37	38	Actuator Power
ERROR REPORT BUSS				39	40	Common

NOTES:

CABLE #: 6 ORIGINATOR: [redacted] B. DATE: 4/2/88

SOURCE: TSC DESTINATION: TS-6

ADDRESS-BIT	SIGNAL NAME	WIRE #		SIGNAL NAME
Ø A 0	Sylvester Jr. (cont.) L. wrist	1	2	Actuator Power
Ø A 1	R. Arm up	3	4	Actuator Power
Ø A 2	R. Wrist	5	6	Actuator Power
Ø A 3	tweety mouth 4 + 1 unmirted	7	8	Actuator Power
ERROR REPORT BUSS		9	10	Common
Ø A 4	EYES UP	11	12	Actuator Power
Ø A 5	Eyes down	13	14	Actuator Power
Ø A 6	Head [redacted]	15	16	Actuator Power
Ø A 7	Special Effects Lower	17	18	Actuator Power
ERROR REPORT BUSS	[redacted]	19	20	Common
Ø B 0	Scene change 1	21	22	Actuator Power
Ø B 1	Scene change 2	23	24	Actuator Power
Ø B 2	Pepe Le Pew mouth	25	26	Actuator Power
Ø B 3	EYES L.	27	28	Actuator Power
ERROR REPORT BUSS		29	30	Common
Ø B 4	Eyes R.	31	32	Actuator Power
Ø B 5	Eye lid 1	33	34	Actuator Power
Ø B 6	Eye Lid 2	35	36	Actuator Power
Ø B 7	Head Rock	37	38	Actuator Power
ERROR REPORT BUSS		39	40	Common

card 3

NOTES:

FACILITY: Looney Tunes Trailer

CABLE #: 7 ORIGINATOR: Scott B. DATE: 9/2/86

SOURCE: TSC DESTINATION: TS-7

Card 4

(card slot 3)

ADDRESS-BIT	SIGNAL NAME	WIRE #		SIGNAL NAME
Ø C 0	Pepe Le Pew (cont.) Head turn	1	2	Actuator Power
Ø C 1	Body turn	3	4	Actuator Power
Ø C 2	L. elbow	5	6	Actuator Power
Ø C 3	L. wrist	7	8	Actuator Power
ERROR REPORT BUSS		9	10	Common
Ø C 4	R. elbow	11	12	Actuator Power
Ø C 5	R wrist	13	14	Actuator Power
Ø C 6	Legs	15	16	Actuator Power
Ø C 7	tail	17	18	Actuator Power
ERROR REPORT BUSS		19	20	Common
Ø D 0	Porky Pig mouth	21	22	Actuator Power
Ø D 1	Eyes & Head L.	23	24	Actuator Power
Ø D 2	Eyes & Head R.	25	26	Actuator Power
Ø D 3	Eyes up	27	28	Actuator Power
ERROR REPORT BUSS		29	30	Common
Ø D 4	Eyes down	31	32	Actuator Power
Ø D 5	Eye Brows	33	34	Actuator Power
Ø D 6	Head Rock L.	35	36	Actuator Power
Ø D 7	Head Rock R.	37	38	Actuator Power
ERROR REPORT BUSS		39	40	Common

NOTES:

FACILITY: Looney Tunes Trailer

CABLE #: 8 ORIGINATOR: Scott B. DATE: 9/2/86

SOURCE: TSC DESTINATION: TS-8

ADDRESS-BIT	SIGNAL NAME	WIRE #		SIGNAL NAME
Ø E 0	Porky Head Bob	1	2	Actuator Power
Ø E 1	" Body Turn L	3	4	Actuator Power
Ø E 2	" " " R	5	6	Actuator Power
Ø E 3	" " Bob	7	8	Actuator Power
ERROR REPORT BUSS		9	10	Common
Ø E 4	Porky Arms Up	11	12	Actuator Power
Ø E 5	MAIN CURTAIN	13	14	Actuator Power
Ø E 6	Daffy Curtain	15	16	Actuator Power
Ø E 7	S/y CURTAIN	17	18	Actuator Power
ERROR REPORT BUSS		19	20	Common
Ø F 0	Oleo 1 Front Rock & Roll	21	22	Actuator Power
Ø F 1	Oleo 2 Rear Chorus line	23	24	Actuator Power
Ø F 2	Henry Hawk Mouth	25	26	Actuator Power
Ø F 3	" " Eyes & Body Turn	27	28	Actuator Power
ERROR REPORT BUSS		29	30	Common
Ø F 4	Henry Hawk Head Rock	31	32	Actuator Power
Ø F 5	" " " Bob	33	34	Actuator Power
Ø F 6	" " WRIST TURN	35	36	Actuator Power
Ø F 7	" " Lift	37	38	Actuator Power
ERROR REPORT BUSS		39	40	Common

NOTES:

FACILITY: Looney Tunes Trailer

CABLE #: 9 ORIGINATOR: Scott B DATE: 9/2/86

SOURCE: TSC DESTINATION: TS-9

Card 5

(Card slot 4)

ADDRESS-BIT			SIGNAL NAME	WIRE #		SIGNAL NAME
1	Ø	0	Daffy Spot Dimmer 1	1	2	Actuator Power
1	Ø	1	Hawk Spot Dimmer 2	3	4	Actuator Power
1	Ø	2	Speedy Spot Dimmer 3	5	6	Actuator Power
1	Ø	3	Porky " " 4	7	8	Actuator Power
ERROR REPORT BUSS				9	10	Common
1	Ø	4	Pepe Spot " 5	11	12	Actuator Power
1	Ø	5	Bugs Spot " 6	13	14	Actuator Power
1	Ø	6	Y. Sam Spot " 7	15	16	Actuator Power
1	Ø	7	Sylv. Spot " 8	17	18	Actuator Power
ERROR REPORT BUSS				19	20	Common
1	1	0	Tweety Spot & Overhead " 9	21	22	Actuator Power
1	1	1	Bugs Overhead " 10	23	24	Actuator Power
1	1	2	Pepe Magenta Overhead " 11	25	26	Actuator Power
1	1	3	" Overhead white " 12	27	28	Actuator Power
ERROR REPORT BUSS				29	30	Common
1	1	4	Daffy Overhead white " 13	31	32	Actuator Power
1	1	5	" " Red " 14	33	34	Actuator Power
1	1	6	" " Blue " 15	35	36	Actuator Power
1	1	7	Stage Wash Blue " 16	37	38	Actuator Power
ERROR REPORT BUSS				39	40	Common

NOTES:

FACILITY: LOONEY TUNES TRAILER

CABLE #: 10 ORIGINATOR: SCOTT DATE: 4/2/86

SOURCE: TSC DESTINATION: TS-10

ADDRESS-BIT			SIGNAL NAME	WIRE #		SIGNAL NAME
1	2	0	STAGE WASH Red	1	2	Actuator Power
1	2	1	STAGE WASH	3	4	Actuator Power
1	2	2		5	6	Actuator Power
1	2	3		7	8	Actuator Power
ERROR REPORT BUSS				9	10	Common
1	2	4		11	12	Actuator Power
1	2	5		13	14	Actuator Power
1	2	6		15	16	Actuator Power
1	2	7		17	18	Actuator Power
ERROR REPORT BUSS				19	20	Common
1	3	0		21	22	Actuator Power
1	3	1		23	24	Actuator Power
1	3	2		25	26	Actuator Power
1	3	3		27	28	Actuator Power
ERROR REPORT BUSS				29	30	Common
1	3	4		31	32	Actuator Power
1	3	5		33	34	Actuator Power
1	3	6		35	36	Actuator Power
1	3	7		37	38	Actuator Power
ERROR REPORT BUSS				39	40	Common

NOTES: